FACTORY DIRECT LIGHTING

# Installation Manual for Remote controller

| Remote Control Settings | Button | Remarks |
|---|---|---|




| Button | Remarks |
|---|---|
| ON OFF | Press the “ON/OFF” button, the light goes to constant on/off mode, sensor is disable.<br>Short press the “M/R” button, the sensor starts to work. |
| M/R | Short press “M/R” button, all parameters back to the last settings.<br>Long press “M/R” button, all parameters back to factory settings. |
| 10% 30% | Stand-by dim level<br>Set up stand-by dim level: 10%/ 30% |
| 25% 50% 100% | Detection Area<br>Set up detection area: 25%/ 50%/ 100% |
| DIM+ DIM- | Short press “DIM+/DIM-” button to transmit dimming signal. The brightness of the lamp adjust at 5% per unit, from 50% to 100%. |
| 0s 1min 30min +∞ | Stand-by period<br>Set up stand-up time: 0s/ 1min/ 30min/ +∞ |
| 5Lux 15Lux 50Lux Disable | Daylight sensor<br>Set up daylight threshold: 5lux/ 15lux/ 50lux/ disable |
| 5s 1min 5min 10min | Hold time<br>Set up hold time: 5s/ 1min/ 5min/ 10min |